# Vitro Fitting Guide - Distance Selection

| Part Number | Description | Machines that can be applied |
|---|---|---|
| 41524650 | KIT Distance Selection | VITRO |

41524650: BILL OF MATERIALS:

| Item | Part No. | Description | Qty |
|---|---|---|---|
| 1 | 43315790 | Button C/Board (58547) | 1 |
| 2 | 43234100 | Distance Selection Link (Fitted to PCB) | 1 |
| 3 | 82045430 | Point of Sale Sticker | 1 |
| 4 | 81066720 | Installation Instruction | 1 |

# Vitro Fitting Guide - Distance Selection

1. Turn the machine off.
2. Open the machine door.
3. Remove screws to access the boards inside the door.

4. Take a picture of the connections on the button control board.
5. Carefully disconnect looms from button control board.
6. Remove button control board.



# Vitro Fitting Guide - Distance Selection

7. Fit new button control board with link.
8. Reconnect looms to button control board
9. Check connections with your photo.




10. Turn the machine back on.
11. Check that the keypads have come on, if not check your connections.
12. Test vend each drink by holding your finger 2cm from the glass.



13. For machines WITHOUT payment system or programmed in FREE VEND mode, configure the ‘GO’ key in touch panel is recommended by Coffetek in order to avoid non desired services.

# Vitro Fitting Guide - Distance Selection

14. Fit instruction label to front glass.